












PANO YEDEK PARÇA LİSTESİ CONTROLLER SPARE PARTS LIST

NO	MALZEME ADI / DESCRIPTION OF MATERIAL	KOD / CODE	FOTOĞRAF / PHOTO
1	ML20E KONTROL KARTI (CONTROL CARD)	05.08.00.0008	
2	ML60X KONTROL KARTI (CONTROL CARD)	05.08.00.0009	
3	ML65X KONTROL KARTI (CONTROL CARD)	05.08.00.0034	
4	ML70S KONTROL KARTI HAZIR TESİSAT (CONTROL CARD / PREWIRED)	05.08.00.0060	
5	ML40P KONTROL KARTI 81-20 (CONTROL CARD)	05.08.00.0117	
6	ML50S KONTROL KARTI 81-20 HAZIR TESİSAT (CONTROL CARD / PREWIRED)	05.08.00.0119	
7	MLCOMBO 40 TÜMLEŞİK CİHAZ (INTEGRATED DEVICE)	7.5KW-05.10.07.0155 11KW-05.10.07.0154	



8	MLCOMBO X 5,5KW TMLEŐİK KONTROL CİHAZI (INTEGRATED CONTROL DEVICE)	05.10.07.0181	
9	MLCOMBO X 7,5KW TMLEŐİK KONTROL CİHAZI (INTEGRATED CONTROL DEVICE)	05.10.07.0178	
10	MLCOMBOX 11KW TMLEŐİK KONTROL CİHAZI (INTEGRATED CONTROL DEVICE)	05.10.07.0162	
11	SERİ 65 KARTI ML65X SERIAL CARD	05.08.00.0036	
12	ML İNT 65 KART ML65X ADDENTION CALL CARD	05.08.00.0045	
13	ML KABİN K CABIN CALL CARD	05.08.00.0082	
14	ML KABİN R	05.08.00.0081	

15	ML SERİ 40	05.08.00.0118	
16	ML SERİ SES KARTI	05.08.00.0160	
17	ML KDK (KUYU DİBİ KARTI) (PIT TERMINAL CARD)	05.08.00.0135	
18	I BOX P	05.08.00.0199	
19	TERM P	05.08.00.0198	
20	I BOX S	05.10.07.0188	
21	TERM S	05.10.07.0187	

22	ENCOD-A	05.10.07.0180	
23	ML POWER	80.06.03.0079	
24	ML KS10	05.08.00.0016	
25	ARL 200 S KONTROL KARTI (CONTROL CARD)	05.08.00.0031	
26	ARL 300 KONTROL KARTI (CONTROL CARD)	05.08.00.0051	
27	ARL 700 KONTROL KARTI (81-20) (CONTROL CARD)	05.08.00.0152	
28	ARCODE TÜMLEŞİK ASANSÖR KONTROL ÜNİTESİ (14,17,26,35,50,75) AMPER (INTEGRATED LIFT CONTROL UNIT)	14A-4221021103221020 17A-4322021103221010 26A-4223021103221010 35A-4124001102221010 50A-3125071102221010 75A-3129071102221010	


29	A DRIVE SÜRÜCÜ (5.5,7.5,11,15,22 KW) (SPEED CONTROLLER DEVICE)	05.08.00.0149	
30	FX SERİ	05.08.00.0032	
31	REVBA KARTI	05.08.00.0107	
32	FX SERİ 32	05.08.00.0057	
33	APRE KARTI	05.08.00.0105	
34	AUTO KG KARTI	05.08.00.0085	
35	IBCS	05.10.07.0112	

36	FXCAN	05.08.00.0146	
37	KDB	05.08.00.0143	
38	CPC	05.10.07.0059	
39	CPC-T	05.10.07.0081	
40	KBK12 - 13	05.08.00.0157	
41	ETM	05.08.00.0094	
42	IO210	05.08.00.0151	


43	ENCI KARTI	05.10.07.0080	
44	ENCA KARTI	05.10.07.0060	
45	MSP32	05.08.00.0162	
46	MSP16	05.08.00.0153	
47	HSR	05.08.00.0154	
48	G&Z PLUS	05.08.00.0171	
49	AREM MOBILE	05.10.07.0177	



50	AREM EL TERMİNALİ (HAND TERMINAL)	05.10.07.0062	
51	DBR KARTI	05.10.07.0061	
52	DFC KARTI	05.08.00.0125	
53	AR LİNE M	05.08.00.0188	
54	ARKEL ARLINE S-INT	05.08.00.0191	
55	ARKEL ARLINE S-TP KONUŞMA ÜNİTESİ SPEECH UNIT	05.08.00.190	
56	ARKEL SCOP KONUŞMA ÜNİTESİ SPEECH UNIT	05.08.00.189	

57	AR LİFT	05.10.07.0163	
58	SERVOSAN 1000VA KURTARMA KARTI (RESCUE CARD)	05.08.00.0038	
59	SERVOSAN 1500 VA KURTARMA KARTI (RESCUE CARD)	05.08.00.0108	
60	30A EMC FİLTRE (FILTER)	05.10.07.0010	
61	50A EMC FİLTRE (FILTER)	05.10.07.0026	
62	2500 WATT FRENLEME DİRENCİ 18 OHM (BRAKE RESISTANCE)	05.10.07.0001	
63	2500 WATT FRENLEME DİRENCİ 25 OHM (BRAKE RESISTANCE)	05.10.07.0014	

64	2500 WATT FRENLEME DİRENCİ 40 OHM (BRAKE RESISTANCE)	05.10.07.0132	
65	2500 WATT FRENLEME DİRENCİ 50 OHM (BRAKE RESISTANCE)	05.10.07.0133	
66	PAKO ŞALTER (25,32,40,63 AMPER) (PACK SWITCH)	25A-05.10.02.0026 32A-05.10.02.0025 40A-05.10.02.0024 63A-05.10.02.0036	
67	4 LÜ KESİCİLER (QUARTERNARY CUTTERS)	25A-05.10.06.0009 32A-05.10.06.0034 40A-05.10.06.0036	
68	3 LÜ KESİCİLER (25,32,40 AMPER) (TRIPLE CUTTERS)	25A-05.10.06.0028 32A-05.10.06.0042 40A-05.10.06.0043	
69	TEKLİ KESİCİLER (2,4,6,10,16 AMPER) (SINGLE CUTTERS)	2A-05.10.06.0003 4A-05.10.06.0005 6A-05.10.06.0006 10A-05.10.06.0007 16A-05.10.06.0046	
70	İKİLİ KESİCİLER 25 AMPER (DUAL CUTTERS)	05.10.06.0069	


71	KAÇAK AKIM ROLESİ 25 AMPER/30mA (LEAKAGE RELAY)	05.10.03.0011	
72	DÖRTLÜ KAÇAK AKIM ROLESİ (25,32,40 AMPER) (QUARTERNARY LEAKAGE RELAY)	05.10.06.0038 -32 YOK- 05.10.06.0039	
73	DARBE AKIM ŞALTERİ 2P16AX250V (IMPULSE CURRENT SWITCH)	05.10.03.0039	
74	LC1D258M7 KONTAKTÖR (CONTACTOR)	05.10.01.0013	
75	LC1D188M7 KONTAKTÖR (CONTACTOR)	05.10.01.0015	
76	LC1E2501 KONTAKTÖR (CONTACTOR)	05.10.01.0052	
77	LC1E2510M5 KONTAKTÖR (CONTACTOR)	05.10.01.0055	


78	LC1E1801M5 KONTAKTÖR (CONTACTOR)	05.10.01.0067	
79	LC1E1201 KONTAKTÖR (CONTACTOR)	05.10.01.0063	
80	LAEN 20 YARDIMCI KONTAK (AUXILIARY CONTACTS)	05.10.01.0062	
81	LAEN 22 YARDIMCI KONTAK (AUXILIARY CONTACTS)	05.10.01.0059	
82	LADN 13 YARDIMCI KONTAK (AUXILIARY CONTACTS)	05.10.01.0046	
83	LAEN11 YARDIMCI KONTAK (AUXILIARY CONTACTS)	05.10.01.0050	
84	LAEN 02 YARDIMCI KONTAK (AUXILIARY CONTACTS)	05.10.01.0054	

85	LADN20 YARDIMCI KONTAK (AUXILIARY CONTACTS)	05.10.01.0032	
86	LADN 22 YARDIMCI KONTAK (AUXILIARY CONTACTS)	05.10.01.0002	
87	24V DC RÖLE (RELAY)	05.10.03.0036	
88	230V AC RÖLE (RELAY)	05.10.03.0037	
89	5.5-8A TERMİK RÖLE (LRE12) (THERMAL RELAY)	05.10.03.0017	
90	7-10A TERMİK RÖLE (LRE14) (THERMAL RELAY)	05.10.03.0019	
91	9-13A TERMİK RÖLE (LRE16) (THERMAL RELAY)	05.10.03.0018	

92	12-18A TERMİK RÖLE (LRE21) (THERMAL RELAY)	05.10.03.0021	
93	16-24A TERMİK RÖLE (LRE22) (THERMAL RELAY)	05.10.03.0020	
94	20-25A MOTOR KORUMA ŞALTERLERİ (ENGINE PROTECTION SWITCHES)	05.10.02.0019	
95	24-32A MOTOR KORUMA ŞALTERLERİ (ENGINE PROTECTION SWITCHES)	05.10.02.0007	
96	30-40A MOTOR KORUMA ŞALTERLERİ (ENGINE PROTECTION SWITCHES)	05.10.02.0015	
97	37-50A MOTOR KORUMA ŞALTERLERİ (ENGINE PROTECTION SWITCHES)	05.10.02.0016	
98	48-65A MOTOR KORUMA ŞALTERLERİ (ENGINE PROTECTION SWITCHES)	05.10.02.0017	

99	56-80A MOTOR KORUMA ŞALTERLERİ (ENGINE PROTECTION SWITCHES)	05.10.02.0001	
100	MANDAL BUTON KALICI (LAY5DB2ED21) (LATCH BUTTON)	05.10.10.0076	
101	SARI YAYLI BUTON (LAY5DB2EA42) (YELLOW PUSH BUTTON)	05.10.10.0173	
102	KONTAK BLOK NO (LAY5DB2BE101) (CONTACT BLOCK)	05.10.10.0079	
103	KONTAK BLOK NC (LAY5DB2BE102) (CONTACT BLOCK)	05.10.10.0080	
104	KXDUB KABLO GRUBU (WIRE GROUP)	05.08.00.0144	
105	BTX KABLO GRUBU (WIRE GROUP)	05.10.07.0124	

106	CBK10 KABLO GRUBU (WIRE GROUP)	05.10.09.0091	
107	KBL-DIC1 KABLO GRUBU (WIRE GROUP)	05.10.09.0096	
108	CBK4.5 KABLO GRUBU (WIRE GROUP)	05.10.09.0093	
109	KBL-DIC3 KABLO GRUBU (WIRE GROUP)	05.10.09.0095	
110	CBI 2 KABLO GRUBU (WIRE GROUP)	05.10.09.0094	
111	KBL - D1C2 KABLO GRUBU (WIRE GROUP)	05.10.09.0097	
112	D1CT KABLO GRUBU (WIRE GROUP)	05.10.07.0116	 

113	ACOP KABLO GRUBU (WIRE GROUP)	05.10.09.0090	
114	KXCBA KABLO GRUBU (WIRE GROUP)	05.10.07.0071	
115	DCN-3 KABLO GRUBU (WIRE GROUP)	05.10.09.0098	
116	DCN-2 KABLO GRUBU (WIRE GROUP)	05.10.09.0100	
117	DCN-1 KABLO GRUBU (WIRE GROUP)	05.10.09.0099	
118	DCN-T KABLO GRUBU (WIRE GROUP)	80.06.03.0075	
119	ASGKD702-M KUYU DİBİ KUTUSU (PITBOX)	05.10.11.0028	

120	ASGKD702-A KUYU DİBİ KUTUSU (PITBOX)	05.10.11.0027	
121	180VA 220/20-220 TRANSFORMATÖR (TRANSFORMER)	05.10.04.0006	
122	160VA 220/20-220 TRANSFORMATÖR (TRANSFORMER)	05.10.04.0137	
123	60VA 220/55 VOLT TRANSFORMATÖR (TRANSFORMER)	05.10.04.0009	
124	PAKO ŞALTER KUTUSU EN81-1 (PACK SWITCH BOX)	05.10.11.0030	
125	EL TERMİNALİ N81-20 (HAND TERMINAL)	05.10.10.0182	
126	EL TERMİNALİ JOS444P (HAND TERMINAL)	05.10.10.0006	

127	KUYU DİBİ REVİZYON RESET ANAHTARI (PIT REVISION RESET SWITCH)	05.10.10.0258	
128	LBYP BYPASS FLAŞÖR SESLİ İKAZ (BUZZER)	05.10.10.0202	
129	SLS KUYU AYDINLATMA BUTONU (PIT LIGHTING BUTTON)	05.10.10.0203	
130	KUYU DİBİ MUHAFAZALI MANTAR STOP(KUTULU) (PIT PROTECTED STOP BOX)	05.10.10.0198	